



MP100U 電容式麥克風

1. 硬體安裝



2. 按鈕/旋鈕功能說明






項目	說明
音量旋鈕	增大麥克風音量：向右旋轉。 降低麥克風音量：向左旋轉。
迴音旋鈕	增大人聲迴音效果：向右旋轉。 降低人聲迴音效果：向左旋轉。
耳機監聽	連接3.5mm耳機，可即時監聽聲音。
靜音按鈕	藍燈：麥克風On。 綠燈：麥克風Off。

3. 麥克風設定

3-1 Windows

※在此以 Windows 10 為範例

1. 至右下方「」點選滑鼠左鍵，再至「」點選滑鼠右鍵。
2. 接著至「開啟音效設定(E)」點選滑鼠左鍵。



3. 進入音效後，將輸出設定成「喇叭(USM_MIC)」，輸入設定成「喇叭(USM_MIC)」即完成設定。

The image shows the Windows Settings application window titled "設定" (Settings). The left sidebar contains a search bar "尋找設定" and a list of system settings categories: 首頁 (Home), 系統 (System), 顯示器 (Display), 音效 (Sound), 通知與動作 (Notifications & Actions), 專注輔助 (Focus Assist), 電源與睡眠 (Power & Sleep), 電池 (Battery), 儲存體 (Storage), 平板 (Tablet), 多工 (Taskbar & Navigation), 投影到此電腦 (Project to this PC), 共用體驗 (Sharing), and 剪貼簿 (Clipboard). The "音效" (Sound) category is selected and highlighted in blue. The main content area is titled "音效" (Sound) and has standard window controls (minimize, maximize, close) in the top right. Under the "輸出" (Output) section, the "選擇輸出裝置" (Choose output device) dropdown menu is set to "喇叭 (USB_MIC)" and is highlighted with a red box. Below this, a note states: "部分應用程式可能會設定為使用其他音訊裝置，而非此處選取的裝置。您可在進階音訊選項中自訂應用程式音量和裝置。" (Some apps may be configured to use other audio devices instead of the one selected here. You can customize app volume and devices in advanced audio options.) Under the "裝置內容" (Device content) section, the "主音量" (Master volume) slider is set to 100. Below the slider is a "疑難排解" (Troubleshoot) button. Under the "管理音效裝置" (Manage audio devices) section, the "輸入" (Input) section is visible, with the "選擇輸入裝置" (Choose input device) dropdown menu set to "麥克風 (USB_MIC)" and highlighted with a red box. A similar note is provided below the input device selection.


3-2 MacOS

※在此以 macOS 12 為範例。

1. 點選系統偏好設定。



2. 進入系統偏好設定後，點選「聲音」。



3. 將輸出、輸入都設定成「USB_MIC」即完成設定。

輸出



輸入

